Power Play
USER'S GUIDE

for XBOX 360™

No more worrying about if your battery pack is fully charged. Avoid the pesky problem of your battery pack losing power during game play. With dreamGEAR's Power Play Charging Cable for the Xbox 360, you can charge your controller and play at the same time!

dreamGEAR®
www.dreamgear.net

TO USE:

Insert the Charging Cable to the charge port located on the top of the controller.

NOTE: Connecting the Charging Cable to the controller WITHOUT a rechargeable battery pack, may damage the controller.

1) Connect the Charging Cable to a designated controller port.
2) Turn on your Xbox 360 console.

TROUBLESHOOTING

Problem: Charge time is too slow

Solution: When charging and playing at the same time, the battery pack takes longer to charge. Certain games require vibration; this will also increase the charge time.

NOTE: When a battery pack is depleted, it may take up to 20 minutes to charge and power a controller using the Power Play Charging Cable.

Problem: The charging light doesn't glow

Solution: Make sure the battery pack is completely locked into the battery compartment. Detach and re-attach both the battery and the Power Play Charging Cable a few times. Check the contacts to see if they are dirty or have been damaged.

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net